

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://qianzhu.nt-rt.ru/> || quz@nt-rt.ru

Half hydraulic folder machine

Heavy duty steel fabricated frame provides accurate bends;

Hydraulic bending with manual clamp;

Roving foot pedal incorporates control panel for maximum flexibility;

Extended fingers allows bending of pans or boxes to a depth of 230mm;

Ground segmented fingers can be repositioned to suit many applications;

Easy to use single angle programmable controller incorporating digital readout for angles from 0° ~ 130°;

Auto cycle after clamping bottom beam will bend to pre-set angle and return, head unclamps to set position;

Safety top beam support stop lever located on right side of machine;

Adjustable beam for varying material thickness;

Includes rear 650mm manual back gauge.



Model	Folder Length (mm)	Folder Thickness (mm)	Max. lift of the upper beam (mm)	Evolving angle of the bending beam	Weight (kg)	Main Motor (KW)	Dimension(mm) (L.H.W)
MP-2x2500	2500	0.5-2.0	200	0°~120°	2000	4	3000x1500x810
MP-1.5x3050	3050	0.5-1.5	200	0°~120°	2600	4	3600x1500x810